

# TOSHIBA

Leading Innovation >>>

## *Air to Air Heat Exchanger* **Owner's Manual**

---

### **Concealed Microcomputer Control Type**

Model name: \_\_\_\_\_

**VN-M150HE**

**VN-M250HE**

**VN-M350HE**

**VN-M500HE**

**VN-M650HE**

**VN-M800HE**

**VN-M1000HE**

**VN-M1500HE**

**VN-M2000HE**

For commercial use

**Original instruction**

Thank you very much for purchasing TOSHIBA Air to Air Heat Exchanger.  
 Please read this owner's manual carefully before using your Air to Air Heat Exchanger.

- Obtain the "Owner's manual" and "Installation manual" from constructor (or dealer).

Request to constructor or dealer

- Please clearly explain the contents of the Owner's manual and hand over it.

This appliance is not intended for use by person (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

# Contents

<b>1</b>	<b>Precautions for safety</b> .....	<b>2</b>
<b>2</b>	<b>Features</b> .....	<b>4</b>
<b>3</b>	<b>Standard installation example</b> .....	<b>4</b>
<b>4</b>	<b>System configuration</b> .....	<b>5</b>
<b>5</b>	<b>Part names and functions</b> .....	<b>6</b>
<b>6</b>	<b>How to use</b> .....	<b>9</b>
<b>7</b>	<b>Timer operation</b> .....	<b>10</b>
<b>8</b>	<b>Maintenance</b> .....	<b>11</b>
<b>9</b>	<b>Specifications</b> .....	<b>11</b>
<b>10</b>	<b>Before calling for service</b> .....	<b>13</b>
<b>11</b>	<b>Troubleshooting</b> .....	<b>13</b>

Please read carefully through these instructions that contain important information which complies with the "Machinery" Directive (Directive 2006/42/EC), and understand them.

**Generic Denomination: Air to Air Heat Exchanger**

**Definition of Qualified Installer or Qualified Service Person**

The Air to Air Heat Exchanger must be installed, maintained, repaired and removed by a qualified installer or qualified service person. When any of these jobs is to be done, ask a qualified installer or qualified service person to do them for you. A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the table below.

Agent	Qualifications and knowledge which the agent must have
Qualified installer	<ul style="list-style-type: none"> <li>• The qualified installer is a person who installs, maintains, relocates and removes the Air to Air Heat Exchangers made by Toshiba Carrier Corporation. He or she has been trained to install, maintain, relocate and remove the Air to Air Heat Exchangers made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations.</li> <li>• The qualified installer who is allowed to do the electrical work involved in installation, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the Air to Air Heat Exchangers made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.</li> <li>• The qualified installer who is allowed to work at heights has been trained in matters relating to working at heights with the Air to Air Heat Exchangers made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.</li> </ul>
Qualified service person	<ul style="list-style-type: none"> <li>• The qualified service person is a person who installs, repairs, maintains, relocates and removes the Air to Air Heat Exchangers made by Toshiba Carrier Corporation. He or she has been trained to install, repair, maintain, relocate and remove the Air to Air Heat Exchangers made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations.</li> <li>• The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the Air to Air Heat Exchangers made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.</li> <li>• The qualified service person who is allowed to work at heights has been trained in matters relating to working at heights with the Air to Air Heat Exchangers made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.</li> </ul>

## ■ Warning indications on the Air to Air Heat Exchanger

Warning indication		Description
	<b>WARNING</b> <b>ELECTRICAL SHOCK HAZARD</b> Disconnect all remote electric power supplies before servicing.	<b>WARNING</b> <b>ELECTRICAL SHOCK HAZARD</b> Disconnect all remote electric power supplies before servicing.
	<b>WARNING</b> Moving parts. Do not operate unit with inspection cover removed. Stop the unit before the servicing.	<b>WARNING</b> Moving parts. Do not operate unit with inspection cover removed. Stop the unit before the servicing.
	<b>CAUTION</b> High temperature parts. You might get burned when removing this cover.	<b>CAUTION</b> High temperature parts. You might get burned when removing this cover.

# 1 Precautions for safety

## WARNING

### General

- Carefully read Owner's Manual before starting the Air to Air Heat Exchanger. There are many important things to keep in mind for daily operation.
- Ask for installation to be performed by the dealer or a professional. Only a qualified installer (\*1) is able to install an Air to Air Heat Exchanger. If a non-qualified person installs an Air to Air Heat Exchanger, it may result in problems such as fire, electric shock, injury, water leakage, noise and vibration.

### Transportation and storage

- When transporting the Air to Air Heat Exchanger, wear shoes with protective toe caps, protective gloves, and other protective clothing.
- When transporting the Air to Air Heat Exchanger, do not take hold of the bands around the packing carton. You may injure yourself if the bands should break.
- When stacking the packing cartons for storage or transportation, heed the precautions written on the packing cartons. Failure to heed the precautions may cause the stack to collapse.
- The Air to Air Heat Exchanger should be transported in stable condition. If any part of the product broken, contact your dealer.
- Use a hand truck or forklift to carry the unit. When carrying it by human power, have four persons or more (VN-M150 to 1000HE) eight persons or more (VN-M1500 and 2000HE); otherwise, you may strain your back.

### Installation

- Only a qualified installer(\*1) or qualified service person(\*1) is allowed to carry out the electrical work of the Air to Air Heat Exchanger. Under no circumstances must this work be done by an unqualified individual since failure to carry out the work properly may result in electric shocks and/or electrical leaks.
- After the installation work has been completed, have the installer explain about the circuit breaker positions. In the event that trouble has occurred in the Air to Air Heat Exchanger, set the circuit breaker to the OFF position, and contact a service person.
- Do not install the Air to Air Heat Exchanger in a location that may be subject to a risk of exposure to a combustible gas. If a combustible gas leaks and becomes concentrated around the unit, a fire may occur.
- Use the company-specified products for the separately purchased parts. Use of non-specified products may result in fire, electric shock, water leakage or other trouble. Have the installation performed by a professional.
- Confirm that earthing is performed correctly.

### Operation

- Before opening the electrical control cover or inspection cover of the Air to Air Heat Exchanger, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer(\*1) or qualified service person(\*1) is allowed to remove the electrical control cover or inspection cover of the Air to Air Heat Exchanger and do the work required.
- Inside the Air to Air Heat Exchanger are high-voltage areas and rotating parts. Due to the danger of electric shocks or of your fingers or physical objects becoming trapped in the rotating parts, do not remove the electrical control cover or inspection cover of the Air to Air Heat Exchanger. When work involving the removal of these parts is required, contact a qualified installer or a qualified service person.
- Do not move or repair any unit by yourself. Since there is high voltage inside the unit, you may get electric shock when removing the cover and main unit.
- Use of a stand more than 50 cm high to clean the filter or heat exchange element of the Air to Air Heat Exchanger or to carry out other such jobs constitutes working at heights. Due to the danger of falling off the stand and injuring yourself while working at heights, this kind of work should not be done by unqualified individuals. When this kind of work must be carried out, do not do it yourself but ask a qualified installer or a qualified service person to do it for you.
- Do not place any combustion appliance in a place where it is directly exposed to the wind of Air to Air Heat Exchanger, otherwise it may cause imperfect combustion.
- Do not insert your finger or a stick into the air intake or discharge.  
Doing so may result injury as the fan is rotating at high speed inside the unit.

### Repairs

- When you have noticed that some kind of trouble (such as when an error display has appeared, there is a smell of burning, abnormal sounds are heard, water is leaking) has occurred in the Air to Air Heat Exchanger, do not touch the Air to Air Heat Exchanger yourself but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking "out of service" near the circuit breaker, for instance) until qualified service person arrives. Continuing to use the Air to Air Heat Exchanger in the trouble status may cause mechanical problems to escalate or result in electric shocks or other trouble.

- If there is a danger of the Air to Air Heat Exchanger's falling, do not approach the Air to Air Heat Exchanger but set the circuit breaker to the OFF position, and contact a qualified installer or a qualified service person to refit the unit. Do not set the circuit breaker to the ON position until the unit has been refitted.
- Do not modify the products. Do not also disassemble or modify the parts. It may cause a fire, electric shock or injury.

**Relocation**

- When the Air to Air Heat Exchanger is to be relocated, do not relocate it yourself but contact a qualified installer or a qualified service person. Failure to relocate the Air to Air Heat Exchanger properly may result in electric shocks and/or a fire.

(\*1) Refer to the "Definition of Qualified Installer or Qualified Service Person."

**CAUTION**

**To disconnect the appliance from the mains supply**

- Means for disconnection having a contact separation in all poles at least 3 mm must be incorporated in the fixed wiring in accordance with the wiring rules.

**The installation fuse (all types can be used) must be used for the power supply line of this Air to Air Heat Exchanger.**

**Cautions about installation (confirm the following cautions.)**

- Connect the Air to Air Heat Exchanger to an exclusive power supply of the rated voltage, otherwise the unit may break down or cause a fire.

**Cautions about operation**

- Do not use this Air to Air Heat Exchanger for special purpose such as preserving food, precision instruments, art objects, breeding animals, car, vessel, etc.
- Do not touch any switches with wet finger, otherwise you may get an electric shock.
- If the Air to Air Heat Exchanger will not be used for a considerably long time, turn off the main switch or the circuit breaker, for safety.
- Prevent any liquid from falling into the remote controller. Do not spill juice, water or any kind of liquid.
- Do not pour or spray water or detergent on the electric parts. Doing so may cause electric leakage and result in a fire, electric shocks and/or injury.
- Do not install the unit and inside air intake in a place such as a machine factory, chemical plant, or research institute, where acids, alkaline, organic solvents, or coating materials are handled and toxic gases and/or corrosive gases may be produced. Otherwise, gas poisoning may occur and/or the inside of the unit may be eroded or deteriorated. The deterioration and erosion may result in a fire.
- Do not use "Bypass mode" when heating the room in winter. Water condensed on the unit may drip onto the ceiling board and may soil the ceiling.
- Do not use the unit in a place where it is hot (40 °C or higher) or where much oily smoke is produced, and do not directly expose the unit to flame. Doing so may result in a fire.
- Do not expose animals or plants to the wind from the unit. Doing so may harm the animal or plant.
- Do not use a flammable spray near the unit or inside air intake. Doing so may result in a fire.


**Disposal**

Dispose of Air to Air Heat Exchanger in accordance with the 2002/96/EC Directive WEEE (Waste Electrical and Electronic Equipment).

**Information on the transportation, handling and storage of the carton**

**Examples of indication on the carton**

Symbol	Description	Symbol	Description
	Keep dry		Do not drop
	Do not lay down		Stacking height (3 cartons can be stacked in this case)
	This side up		Do not step
	Handle with care		Weight
	Do not roll		Do not clamp

Other cautions	Description
 <p><b>Caution</b> Injury possibility. Don't handle with packing band, or may get injured in case of broken band.</p>	<p><b>CAUTION</b> Injury possibility. Don't handle with packing band, or may get injured in case of broken band.</p>
<p><b>Stacking notice.</b></p> <p>In case that cardboard boxes protrude out of pallet when stacking, lay a 10mm thick plywood over the pallet.</p> 	<p><b>Stacking notice.</b> In case that cardboard boxes protrude out of pallet when stacking. Lay a 10 mm thick plywood over the pallet.</p>

## 2 Features

### ■ Main features

#### ◆ Power saving ventilation

The cost of cooling and heating is reduced thanks to the unit efficiently retrieving thermal energy (outdoor air load) which has been lost during ordinary ventilation.

#### ◆ Space saving

Significant reduction of outdoor air load and the ability to retrieve thermal energy enable the production of smaller air conditioning devices.

#### ◆ Humidity control

When cooling, highly humid outdoor air is conditioned to near the humidity of the dehumidified (cooled) indoor air before being supplied.

When heating, moisture from the indoor air is transferred to the dry outdoor air before the outdoor air is supplied.

#### ◆ Comfortable ventilation

Ventilation without big changes in temperature is realized.

In addition, stable ventilation is possible even in an air tight room due to simultaneous air intake and expulsion.

#### ◆ Sound insulation

Air trunks and heat exchange elements provide sound insulation.

They reduce the incoming of outdoor noise and the outward flow of sounds indoor and help keep the office or shop, and their surroundings quiet.

### ■ About ventilation modes

The unit has three ventilation modes.

- Heat exchange mode  
Exchanging heat between the outdoor and indoor air and making the temperature and humidity of the outdoor air closer to those of the indoor air before supplying it.
- Bypass mode  
Outdoor air is taken into a room as it is. This mode is mainly used in spring and summer.
- Automatic mode
  1. For an Air to Air Heat Exchanger system  
The heat exchange mode and the bypass mode are automatically switched between following the information from the indoor and outdoor temperature sensors in the unit.
  2. For an Air to Air Heat Exchanger system linked with air conditioners  
The heat exchange mode and the bypass mode are automatically switched between depending on the operation status of the air conditioner (cooling, heating, dry, fan, or temperature setting) and the information from the indoor and outdoor temperature sensors in the unit.

#### ⚠ CAUTION


If the outdoor temperature becomes about to 15 °C or less in [Automatic mode] or [Bypass mode], the system will automatically start to run in [Heat exchange mode] regardless of the mode setting to prevent condensation in the Air to Air Heat Exchanger.

\* The indication of the ventilation mode setting does not change.


## 3 Standard installation example

### ■ Concealed microcomputer control type

#### ▼ VN-M150 to 1000HE



#### ▼ VN-M1500 and 2000HE





#### NOTE



The printed indications on the unit become upside-down when the unit is installed upside-down.

# 4 System configuration

The control method of this product differs depending on the system configuration. Operate it following the methods explained in the system configuration examples below.

- For the actual system configuration, ask your dealer or the installer of the product for information.
- Refer also to the installation manuals and owner's manuals of the remote controllers.
- If you use the central remote controller, refer also to its installation manual and owner's Manual.

System example	Operation	Cautions
<p><b>A. Air to Air Heat Exchanger system</b></p>  <p>Remote controller for the Air to Air Heat Exchanger NRC-01HE</p> <p>Remote controller for air conditioner RBC-AMS41E</p>	<ul style="list-style-type: none"> <li>• Using the remote controller for the Air to Air Heat Exchanger NRC-01HE, you can start and stop the unit, control the Ventilation fan speed, and select the ventilation mode.</li> <li>• The remote controllers for the air conditioner RBC-AMT32E are not compatible with the Air to Air Heat Exchanger system. Only ON/OFF operation is available for RBC-AMS41E.</li> </ul> <p>For operation details using the remote controller for the Air to Air Heat Exchanger NRC-01HE, see page 9 "6.How to use".</p>	<p>If two remote controllers are used, the latter operation overrides the former and their indications always reflect the result of the latter operation.</p>
<p><b>B. Air to Air Heat Exchanger system linked with air conditioners</b></p>  <p>Remote controller for air conditioner RBC-AMT32E, AMS41E</p> <p>Remote controller for the Air to Air Heat Exchanger NRC-01HE</p>	<ul style="list-style-type: none"> <li>• The remote controller for the air conditioner or the Air to Air Heat Exchanger can be used to start / stop the whole system.</li> <li>• The remote controller for the air conditioner or the Air to Air Heat Exchanger can be used to start / stop the Air to Air Heat Exchanger separately.</li> <li>• However, setting modifications are required for separate control. Contact your dealer for more information.</li> <li>• The remote controller for the Air to Air Heat Exchanger NRC-01HE can be used to control the Ventilation fan speed and ventilation mode of the Air to Air Heat Exchanger.</li> <li>• The remote controller for air conditioner RBC-AMT32E, AMS41E cannot be used to control the Ventilation fan speed or ventilation mode of the Air to Air Heat Exchanger.</li> </ul> <p>For operation details using the remote controller for the Air to Air Heat Exchanger NRC-01HE, see page 9 "6.How to use".</p>	<p>If two remote controllers are used, the latter operation overrides the former and their indications always reflect the result of the latter operation.</p>

System example	Operation	Cautions
<p><b>C. Central control system</b> (When controlling the air conditioner group and the Air to Air Heat Exchanger group separately)</p>  <p>Central controller for 64/128 units / groups TCB-SC642TLE2 BMS-CM1280TLE</p> <p>Remote controller for air conditioner RBC-AMT32E, AMS41E</p> <p>Remote controller for the Air to Air Heat Exchanger NRC-01HE</p> <p>Remote controller for air conditioner RBC-AMS41E</p>	<ul style="list-style-type: none"> <li>• The central controller can be used to start / stop the whole system and separately start / stop groups of air conditioners and the Air to Air Heat Exchangers. (In this system, the air conditioners and the Air to Air Heat Exchangers are not linked in operation.)</li> <li>• The central controller cannot be used to control the Ventilation fan speed or ventilation mode of the Air to Air Heat Exchanger.</li> <li>• If the remote controller for the Air to Air Heat Exchanger NRC-01HE has been installed, you can start and stop the unit, control the Ventilation fan speed, and select the ventilation mode with the remote controller.</li> <li>• The remote controllers for the air conditioner RBC-AMT32E are not compatible with the Air to Air Heat Exchanger system. Only ON/OFF operation is available for RBC-AMS41E.</li> </ul> <p>For operation details using the remote controller for the Air to Air Heat Exchanger NRC-01HE, see page 9 "6.How to use".</p>	<p>If three control devices are used; the central controller and the remote controllers for the Air to Air Heat Exchanger and the air conditioner, the latter operation overrides the former regardless of which device is used.</p>
<p><b>D. Central control system</b> (When controlling the air conditioners and the Air to Air Heat Exchangers together)</p>  <p>Central controller for 64/128 units / groups TCB-SC642TLE2 BMS-CM1280TLE</p> <p>Remote controller for the Air to Air Heat Exchanger NRC-01HE</p> <p>Remote controller for air conditioner RBC-AMT32E, AMS41E</p>	<ul style="list-style-type: none"> <li>• The central controller can be used to start / stop the whole system. It can also be used to start / stop the Air to Air Heat Exchanger separately.</li> <li>• However, setting modifications are required for separate control. Contact your dealer for more information.</li> <li>• The central controller cannot be used to control the Ventilation fan speed or ventilation mode of the Air to Air Heat Exchanger.</li> <li>• If the remote controller for the Air to Air Heat Exchanger NRC-01HE has been installed, you can control the Ventilation fan speed and ventilation mode of the Air to Air Heat Exchanger with the remote controller.</li> <li>• The remote controller for air conditioner RBC-AMT32E, AMS41E cannot be used to control the Ventilation fan speed and ventilation mode of the Air to Air Heat Exchanger.</li> </ul> <p>For operation details using the remote controller for the Air to Air Heat Exchanger NRC-01HE, see page 9 "6.How to use".</p>	


**NOTE**

The heat exchange element may smell during the initial period of use. However, this is not a malfunction and the smell is harmless.




# 5 Part names and functions

## Concealed microcomputer control type (main unit)

### ▼ VN-M150 to 1000HE



### ▼ VN-M1500 and 2000HE



Unit: mm



Model	A	B	C	Model	A	B	C
VN-M150HE	900	900	290	VN-M650HE	1140	1140	350
VN-M250HE	900	900	290	VN-M800HE	1189	1189	400
VN-M350HE	900	900	290	VN-M1000HE	1189	1189	400
VN-M500HE	1140	1140	350				

Dimensions of hanging parts are not included.


## Remote controller for the Air to Air Heat Exchanger NRC-01HE

### Operation section

- One of these remote controllers can be used to control both indoor air conditioner units and Air to Air Heat Exchangers (up to 8 units in total).
- After setting the operation conditions, you can use the units by just pressing the ON/OFF button.
- Functions concerning controlling the Air to Air Heat Exchanger are explained here. For controlling an air conditioner, refer to the owner's manuals supplied with the air conditioner.



- FAN button (Fan speed select button) (\*1)**  
Selects the desired Fan speed.
- TIMER SET button (Timer set button)**  
Used for timer setting
- TEST button (Test button)**  
Used for service.  
Do not use this button in everyday operations.
- VENT button (Ventilation button)**  
This button is used when the Air to Air Heat Exchanger is in a system linked with air conditioners. Push the button to turn on/off the Air to Air Heat Exchanger. Turning on/off the air conditioner also turn on/off the Air to Air Heat Exchanger.  
\* No Air to Air Heat Exchanger is connected or separate operation of the Air to Air Heat Exchanger is not set, if "⊘" appears on the remote controller display after pushing the button.
- FILTER RESET button (Filter reset button)**  
Resets "FILTER" indication after cleaning.
- SAVE button (Power save operation) (\*1)**  
Use to initiate power saving mode.
- SWING/FIX button (Swing / Louver direction button) (\*1)**  
Use to select automatic swing or fixed louver position.  
\* Not available for concealed duct, slim duct, floor concealed and floor standing cabinet fresh air intake types.
- Operation lamp**  
Lights up during operation.  
Blinks when an error occurs or the protective device activates.
- ON/OFF button**  
Turns on the unit when pressed, and turns it off when pressed again.
- MODE button (Operation mode select button) (\*1)**  
Selects desired operation mode.



**11** button (Unit / Louver select button)

Used for selecting a unit while changing settings if the remote controls two or more units.

**UNIT button:**

If two or more indoor units are controlled by one remote controller, use this button to select a unit to adjust its air blow direction.

**LOUVER button (\*1):** (4-way cassette type 2H series only)

Selects a louver to control when adjusting the louver lock setting or wind direction setting separately for each louver.

**12** button (Temperature set button)

Adjusts the set temperature.

Select the desired set point by pushing TEMP.

or TEMP.

**13** button (Ventilation fan speed button)

Used to select the ventilation fan speed

You can stop 24-hour ventilation temporarily by pressing and holding the button for 4 seconds while is displayed.

**14** button (Ventilation mode button)

Used to select a ventilation mode.

**15** button (Filter elevating button) (\*1)

\* This function is not available.

**OPTION:**

**Remote controller sensor (\*1)**

Normally the temperature sensor of the indoor unit senses the temperature. The temperature around the remote controller can also be sensed. For details, contact your dealer.

\* Do not use the function when the air conditioner is controlled in a group.

(\*1):


This function is not available for Air to Air Heat Exchanger.

"" will be displayed for few seconds when the unit is running in a system equipped with only the Air to Air Heat Exchanger.

◆ Display section


All indicators are displayed on the display example below for explanation. In reality, only the selected options will be displayed. Indications concerning controlling the Air to Air Heat Exchanger are explained here. For indications concerning an air conditioner, refer to the owner's manuals supplied with the air conditioner.

- **SETTING** blinks on the display of the remote controller when the power switch is turned on for the first time. The initial settings progress while **SETTING** is blinking. Start to use the remote controller after **SETTING** has disappeared.



**NOTE**

The LCD may temporarily be blurred due to static electricity.



**1** **SETTING indicator**

Displayed when setting the timer or other functions.

**2** **Operation mode indicator (\*1)**

Indicates the operation mode selected.

**3** **Error indicator**

Displayed when the protective device activates or an error occurs.

**4** **Time indicator**

Indicates time concerning the timer. (Indicates a error code when an error occurs.)

**5** **Timer mode indicator**

Each time you press the button, the indication changes as follows: , , and no timer indication.

**6** **Filter indicator**

Reminder to clean the air filter.

**7** **Test run indicator**

Displayed during a test run.

**8** **Louver position display (\*1)**

Indicates the louver position.


\* Only for 4-way cassette, 1-way cassette, 2-way cassette, under ceiling types

**9** **Swing indicator (\*1)**

Displayed during up/down movement of the louver.

**10** **Set temperature display (\*1)**


The selected set temperature is displayed.



- 11 Remote controller sensor indicator (\*1)**  
Displayed when the remote controller sensor is used.
- 12 Pre-heat indicator (\*1)**  
Displayed when the heating mode is energized or defrost cycle is initiated. While this indication is displayed, the indoor fan stops or operate in fan mode.
- 13 No function indicator**  
Displayed when the function requested is not available on that model.
- 14 Fan speed indicator (\*1)**  
Indicates the selected fan speed:  
 (Auto)   
 (High)   
 (Medium)   
 (Low) 
- 15 Louver Number display. (\*1)**  
(example:01, 02, 03, 04)
- 16 Power saving mode display (\*1)**  
Displayed during capacity saving mode.
- 17 Louver lock indicator (\*1)**  
Displayed when a louver is locked. (4-way cassette type only)
- 18 UNIT No. indicator**  
The number of the Air to Air Heat Exchanger selected using the UNIT button or that of the unit in which an error has occurred.
- 19 Central control indicator**  
Displayed when a central control device such as a central controller is also used. If the central control

device prohibits the use of local remote controllers,  blinks when any of the ,  or TEMP. buttons are pressed and the operation is rejected. The items controllable with the remote differ depending on the mode of central control. Refer to the owner's manual of the central control device you are using for more information

- 20 Operation mode controlled indicator (\*1)**  
Displayed when MODE button is pushed while operation mode is fixed to cool or heat by the air conditioner administrator.



- 21 Operation ready display (\*1)**  
This display appears on some models.
- 22 Service display**  
Displayed while the protective device works or a trouble occurs.
- 23 Ventilation fan speed indicator**  
Indicates the ventilation fan's speed. , ,  or  is indicated. When the remote is used to control air conditioners together with the Air to Air Heat Exchanger as a group, VENT FAN indicator appears (blinks) only when the  button is pressed.  
 (High)   
 (Low)   
 (SA > EA)   
 (SA < EA)  ) \* Displayed when the setting is activated.
- 24 Ventilation mode indicator**  
Indicates the selected ventilation mode. ,  or  is indicated.  
 (Automatic mode)   
 (Heat exchange mode)   
 (Bypass mode) 
- 25 24-hour ventilation indicator**  
Displayed during 24-hour ventilation.  
\* Displayed when the setting is activated.
- 26 Nighttime heat purge indicator**  
Displayed during the nighttime heat purge operation.  
\* Displayed when the setting is activated.
- 27 Ventilation on-standby indicator**  
Displayed while the Air to Air Heat Exchanger is on standby. While this indicator is displayed, the Air to Air Heat Exchanger is not in operation.  
\* Displayed when the setting is activated.
- 28 Ventilation indicator**  
If the remote is used to control the Air to Air Heat Exchanger in the Air to Air Heat Exchanger system linked with air conditioners, and separate operation of the unit is set to available, the indicator is displayed while the unit is running.  
\* The indicator is not displayed when the unit is running in a system equipped with only the Air to Air Heat Exchanger.

(\*1):  
Not displayed. These functions are not available for Air to Air Heat Exchanger.

# 6 How to use

## ■ When using the remote controller for the Air to Air Heat Exchanger (NRC-01HE)

When the Air to Air Heat Exchanger is used for the first time or change the settings, operate the remote following the procedure below.  
From the next time, the unit starts running following the set operation conditions by just pressing the button.

### ◆ Preparation


#### Turning on the circuit breaker

When turned on, the separation lines appear and **SETTING** blinks on the display of the remote controller.  
\* The remote controller will not work for about 1 minute after turning on the power. This is not a malfunction.  
\* If an Air to Air Heat Exchanger system linked with air conditioners is used, turn on the circuit breaker for the air conditioners too.

#### REQUIREMENT

- Keep the circuit breaker turned on during use.
- For an Air to Air Heat Exchanger system linked with air conditioners, when the system is used after a long period of disuse, turn on the circuit breaker of the unit and air conditioners 12 hours or more before starting operation.

## ■ Operations




**1** Push the buttons to start operation. The operation lamp lights up.

#### REQUIREMENT

Operation will be started when the heat exchange ventilation is in an Air to Air Heat Exchanger system linked with air conditioners.

**2** Push the button to select the ventilation fan speed.

Each time the button is pushed, the ventilation fan speed and indication changes as follows.




\* The indications and are displayed only when the imbalanced ventilation fan speed setting is activated.

#### REQUIREMENT

As factory default, the imbalanced ventilation fan speed setting is deactivated only [High] and [Low] are available for selection. Consult your dealer to activate the setting.

**3** Push the button to select a ventilation mode.


Each time the button is pushed, the ventilation mode and indication change as follows:



**4** Push the buttons to stop operation. The operation lamp turns off.

## ■ About the separate operation of the Air to Air Heat Exchanger in an Air to Air Heat Exchanger system linked with air conditioners

\* The procedure below is not effective in a system equipped with the Air to Air Heat Exchanger only.




**1** Push the button while the system is running.

Only the Air to Air Heat Exchanger stops and the indicator turns off.

**2** Push the button while the system is stopped.

The indicator lights up and the Air to Air Heat Exchanger starts running separately.



#### NOTE

- Normally, the Air to Air Heat Exchanger ON/OFF as the air conditioner is ON/OFF when it is in an Air to Air Heat Exchanger system linked with air conditioners.
- If " " is displayed when the button is pushed, certain settings need to be changed to operate the unit separately. Consult your dealer to change the settings.

## ■ Functions

### About ventilation modes

\* For details, see "About ventilation modes" on page 4. [Heat exchange mode], [Bypass mode] or [Automatic mode] can be selected.

### About imbalanced ventilation fan speed ( [SA>EA]/ [SA<EA])

#### For normal ventilation (High or Low):

The volumes of the indoor air supply and outdoor air exhaustion are set to the same level.

#### For imbalanced ventilation fan speed:

- When [SA>EA] is selected: the volume of the indoor air supply is larger than that of the outdoor air exhaustion. (Inflow of humidity and smells from the toilet and kitchen is reduced.)
  - When [SA<EA] is selected: the volume of the outdoor air exhaustion is larger than that of the indoor air supply. (Outflow of smells and floating bacteria into a corridor or other places is reduced.)
- \* Consult your dealer if the setting of the imbalanced ventilation fan speed seems incorrect.

### About 24-hour ventilation

- When the 24-hour ventilation setting is active, press the button while the system is running and the operation lamp turns off, appears on the display, and 24-hour ventilation starts.
- Press and hold the button for 4 seconds or more while the indicator is displayed to stop 24-hour ventilation temporarily. The indicator turns off and 24-hour ventilation stops temporarily.

#### NOTE

- The setting of 24-hour ventilation is "OFF" As factory default. Consult your dealer to change the setting to "ON".
- The settings of or cannot be changed during 24-hour ventilation. Their indicators are not displayed.
  - \* During 24-hour ventilation, the unit is running intermittently (stops for 60 minutes after running for 60 minutes) under the settings [LOW] ventilation fan speed and [Heat exchange mode].
- While 24-hour ventilation is running, the indicator stays lit even during the intervals.

### About nighttime heat purge operation

- Nighttime heat purge is a function to reduce the room air conditioning load in the morning in summer by exhausting the air indoor which has become warm while the air conditioner is stopped in the night automatically in the Bypass mode.

- The nighttime heat purge operation functions if night purge is activated and the last operation mode of the air conditioner before stopping is ,  or  in an Air to Air Heat Exchanger system linked with air conditioners.

If the  button is pushed while the system is running, the operation lamp turns off,  appears on the display, and the nighttime heat purge operation turns on-standby.

After the operation becomes on-standby, the unit automatically starts ventilation in [Low] ventilation fan speed and [Bypass mode] when the conditions to start the nighttime heat purge operation below are fulfilled.

The nighttime heat purge operation is paused for one hour if any of the conditions to pause the operation are detected.

If the conditions to start the nighttime heat purge operation are fulfilled one hour after the pause, the operation will start again. If not, the operation will remain paused for one more hour.

This cycle is repeated until the conditions to stop (end) the nighttime heat purge operation below are fulfilled.

#### The conditions to start the nighttime heat purge operation

The unit compares temperatures indoor and outdoor using the monitoring operation (for about 5 minutes) and will start the nighttime heat purge operation if the following conditions are fulfilled.

- A certain amount of time has passed between the nighttime heat purge operation becoming on-standby and the monitoring operation starting. (The time is set between 1- 48 hours in 1 hour steps.)
- The indoor temperature is 3 °C or more higher than the outdoor temperature and the indoor temperature is 2 °C or more higher than the temperature set for the operation.

#### The conditions to pause the nighttime heat purge operation (the operation pauses for one hour.)

- The indoor temperature is the same or lower than the outdoor temperature, the indoor temperature is the same or lower than the temperature set for the operation, or one hour has passed since the nighttime heat purge operation started.

#### The conditions to stop (end) the nighttime heat purge operation

The nighttime heat purge operation ends and the  indicator disappears if any of the following conditions are fulfilled.

- The air conditioner or Air to Air Heat Exchanger is started.
- 48 hours has passed since the monitoring operation started.

#### NOTE

- The setting of the nighttime heat purge operation is "OFF" As factory default. Consult your dealer to change the setting to "ON" or the setting of the time until the monitoring operation starts.
- The settings of  or  cannot be changed during the nighttime heat purge operation. Their indicators are not displayed.
- The  indicator stays lit while the operation is on-standby or paused.
- The nighttime heat purge operation cannot be activated if 24-hour ventilation is activated.

#### CAUTION


The nighttime heat purge operation is not executed if the outdoor temperature becomes about 15°C or less to prevent condensation in the Air to Air Heat Exchanger, but the  indicator is still lit.

## 7 Timer operation

Select a timer type from the following three: (Max. 168 hours)


- OFF timer** : Stops running after a specified period.
- Repeat-OFF timer** : Stops running after a specified period every time the unit is used.
- On timer** : Starts running after a specified period.

### Setting the timer



- Push the  button to start operation. The operation lamp lights up.

- Push the  button. Each time the button is pushed, the timer mode and indication change in the following order:




 and the time indication blink.

- Push the  buttons to set the period of time until the timer actions.


- The time setting increases in 0.5-hour (30 minute) increments each time  is pushed. The setting increases in 1-hour increments if it is over 1 day (24 hours). The maximum is 7 days (168 hours). On the remote controller, settings between 0.5 hours and 23.5 hours (\*1) are displayed as is. For settings over 24 hours (\*2), the days and hours are displayed.
- The time setting decreases in 0.5-hour (30 minute) decrements (0.5 hours to 23.5 hours) or 1-hour decrements (24 hours to 168 hours) each time  is pushed.

Example of indication on the remote controller

- 23.5 hours (\*1)



- 34 hours (\*2)



- 1d indicates 1 day (24 hours).
- 10h indicates 10 hours. (Total: 34 hours)

- Push the  button.

-  disappears, the time indication is displayed, and  or  flashes. (When using the ON timer, all indications other than the time indication and  turn off.)

### Canceling the timer

- Push the  button. The timer indicator disappears.

#### NOTE

- When using the Repeat-OFF timer, pressing the  button after the unit has been stopped by the timer starts it running again, and the unit will stop again after the specified period.
- When 24-hour ventilation or the nighttime heat purge operation is activated, the unit is running the activated operation while the unit stops following the timer setting.

# 8 Maintenance

## ■ Maintenance of the filter and heat exchange element

### ⚠ WARNING

Cleaning the filter and heat exchange element involves dangerous work in high places, have a qualified installer or qualified service person to do it. Do not attempt it by yourself.


### ⚠ CAUTION

Do not push buttons with wet hands. Doing so may result in electric shock.

### ◆ Cleaning the filters

- 1 Clean the filter if “” is indicated on the remote controller.
- 2 Press the “” button after cleaning the filter. The “FILTER RESET” indicator disappears.

\* If the filter or heat exchange element is clogged, the ventilation amount is reduced and ventilation effect will be deteriorated.



### ⚠ CAUTION

#### Cleaning remote controller

- Use a dry cloth to wipe the remote controller.
- Do not use a damp cloth on the remote controller.
- Do not use a chemically-treated duster for wiping or leave such materials on the unit for long. It may damage or fade the surface of the unit.
- Do not use benzene, thinner, polishing powder, or similar solvents for cleaning. These may cause the plastic surface to crack or deform.



# 9 Specifications

## ■ Concealed microcomputer control type

Item	Model No. Fan Speed	VN-M150	VN-M250	VN-M350	VN-M500	VN-M650	VN-M800	VN-M1000	VN-M1500	VN-M2000		
		HE	HE	HE	HE	HE	HE	HE	HE	HE		
Power Supply (V)		Single phase 220-240 V~, 50 Hz 220 V~, 60 Hz										
Power consumption (W)	Heat Exchange Mode	(Extra high)	50Hz	68-78	123-138	165-182	214-238	262-290	360-383	532-569	751-786	1084-1154
			60Hz	76	131	209	260	307	446	622	928	1294
		High	50Hz	59-67	99-111	135-145	176-192	240-258	339-353	494-538	708-784	1032-1080
			60Hz	65	105	162	206	283	408	589	830	1220
		Low	50Hz	42-47	52-59	82-88	128-142	178-191	286-300	353-370	570-607	702-742
			60Hz	45	54	94	144	206	333	411	660	818
	Bypass Mode	(Extra high)	50Hz	68-78	123-138	165-182	214-238	262-290	360-383	532-569	751-786	1084-1154
			60Hz	76	131	209	260	307	446	622	928	1294
		High	50Hz	59-67	99-111	135-145	176-192	240-258	339-353	494-538	708-784	1032-1080
			60Hz	65	105	162	206	283	408	589	830	1220
		Low	50Hz	42-47	52-59	82-88	128-142	178-191	286-300	353-370	570-607	702-742
			60Hz	45	54	94	144	206	333	411	660	818
Current (A)	Heat Exchange Mode	(Extra high)	50Hz	0.31-0.33	0.58-0.61	0.76-0.76	0.99-1.00	1.25-1.30	1.67-1.63	2.47-2.46	3.50-3.30	5.00-4.90
			60Hz	0.36	0.60	0.99	1.20	1.40	2.03	2.84	4.20	5.90
		High	50Hz	0.27-0.28	0.47-0.49	0.62-0.61	0.81-0.81	1.14-1.13	1.57-1.50	2.31-2.28	3.30-3.10	4.80-4.60
			60Hz	0.28	0.49	0.74	0.94	1.30	1.85	2.69	3.80	5.60
		Low	50Hz	0.20-0.20	0.25-0.26	0.38-0.37	0.59-0.60	1.25-1.30	1.31-1.27	1.62-1.57	2.60-2.60	3.30-3.10
			60Hz	0.20	0.25	0.43	0.66	0.95	1.52	1.87	3.00	3.70
	Bypass Mode	(Extra high)	50Hz	0.31-0.33	0.58-0.61	0.76-0.76	0.99-1.00	1.25-1.30	1.67-1.63	2.47-2.46	3.50-3.30	5.00-4.90
			60Hz	0.36	0.60	0.99	1.20	1.40	2.03	2.84	4.20	5.90
		High	50Hz	0.27-0.28	0.47-0.49	0.62-0.61	0.81-0.81	1.14-1.13	1.57-1.50	2.31-2.28	3.30-3.10	4.80-4.60
			60Hz	0.28	0.49	0.74	0.94	1.30	1.85	2.69	3.80	5.60
		Low	50Hz	0.20-0.20	0.25-0.26	0.38-0.37	0.59-0.60	1.25-1.30	1.31-1.27	1.62-1.57	2.60-2.60	3.30-3.10
			60Hz	0.20	0.25	0.43	0.66	0.95	1.52	1.87	3.00	3.70

Item	Model No.		VN-M150 HE	VN-M250 HE	VN-M350 HE	VN-M500 HE	VN-M650 HE	VN-M800 HE	VN-M1000 HE	VN-M1500 HE	VN-M2000 HE	
	Fan Speed											
Maximum running Current (A)	Heat Exchange Mode	(Extra high)	50Hz	0.32-0.33	0.61-0.65	0.81-0.82	1.19-1.23	1.37-1.41	2.15-2.23	2.89-2.94	4.30-4.30	5.60-5.60
			60Hz	0.36	0.65	1.09	1.38	1.59	2.40	3.37	4.90	6.70
		High	50Hz	0.27-0.28	0.46-0.49	0.61-0.62	0.87-0.91	1.17-1.20	1.84-1.94	2.57-2.61	3.80-3.90	5.10-5.10
			60Hz	0.30	0.47	0.73	0.96	1.34	2.01	2.95	4.20	5.90
		Low	50Hz	0.20-0.21	0.25-0.26	0.42-0.44	0.64-0.68	0.90-0.95	1.49-1.58	1.85-1.87	3.10-3.20	3.60-3.80
			60Hz	0.21	0.25	0.45	0.68	0.98	1.59	1.96	3.30	3.90
	Bypass Mode	(Extra high)	50Hz	0.32-0.33	0.61-0.65	0.81-0.82	1.19-1.23	1.37-1.41	2.15-2.23	2.89-2.94	4.30-4.30	5.60-5.60
			60Hz	0.36	0.65	1.09	1.38	1.59	2.40	3.37	4.90	6.70
		High	50Hz	0.27-0.28	0.46-0.49	0.61-0.62	0.87-0.91	1.17-1.20	1.84-1.94	2.57-2.61	3.80-3.90	5.10-5.10
			60Hz	0.30	0.47	0.73	0.96	1.34	2.01	2.95	4.20	5.90
		Low	50Hz	0.20-0.21	0.25-0.26	0.42-0.44	0.64-0.68	0.90-0.95	1.49-1.58	1.85-1.87	3.10-3.20	3.60-3.80
			60Hz	0.21	0.25	0.45	0.68	0.98	1.59	1.96	3.30	3.90
Air Volume (m <sup>3</sup> /h)	(Extra high)	50Hz	150	250	350	500	650	800	1000	1500	2000	
		60Hz	150	250	350	500	650	800	1000	1500	2000	
	High	50Hz	150	250	350	500	650	800	1000	1500	2000	
		60Hz	150	250	350	500	650	800	1000	1500	2000	
	Low	50Hz	110	155	210	390	520	700	755	1200	1400	
		60Hz	110	155	210	390	520	700	755	1200	1400	
External Static Pressure (Pa)	Heat Exchange Mode	(Extra high)	50Hz	82-102	80-98	114-125	134-150	91-107	142-158	130-150	135-156	124-143
			60Hz	99	97	167	181	134	171	185	165	165
		High	50Hz	52-78	34-65	56-83	69-99	58-82	102-132	97-122	103-129	92-116
			60Hz	59	38	33	63	68	102	120	108	102
		Low	50Hz	47-64	28-40	65-94	62-92	61-96	76-112	84-127	112-142	110-143
			60Hz	46	22	39	44	52	58	55	109	87
	Bypass Mode	(Extra high)	50Hz	82-102	80-98	114-125	134-150	91-107	142-158	130-150	135-156	124-143
			60Hz	99	97	167	181	134	171	185	165	165
		High	50Hz	52-78	34-65	56-83	69-99	58-82	102-132	97-122	103-129	92-116
			60Hz	59	38	33	63	68	102	120	108	102
		Low	50Hz	47-64	28-40	65-94	62-92	61-96	76-112	84-127	112-142	110-143
			60Hz	46	22	39	44	52	58	55	109	87

Item	Model No.		VN-M150 HE	VN-M250 HE	VN-M350 HE	VN-M500 HE	VN-M650 HE	VN-M800 HE	VN-M1000 HE	VN-M1500 HE	VN-M2000 HE	
	Fan Speed											
Sound pressure level (dB)	Heat Exchange Mode	(Extra high)	50Hz	26.0-28.0	29.5-30.0	34.0-35.0	32.5-34.0	34.0-36.0	37.0-38.5	39.5-40.5	38.0-39.0	41.0-42.5
			60Hz	27.5	31.5	35.5	33.5	35.5	38	41.5	39.5	42.5
		High	50Hz	24.0-25.5	25.0-27.0	30.0-32.0	29.5-31.0	33.0-34.0	35.5-37.0	38.5-40.0	36.5-37.5	39.5-41.0
			60Hz	24.5	25	29.5	29	34	35	39	36.5	40
		Low	50Hz	20.0-22.0	21.0-22.0	27.0-29.0	26.0-29.0	31.0-32.5	33.5-35.0	34.0-35.5	36.0-37.5	37.0-38.0
			60Hz	20	21	23.5	24.5	29.5	32.5	33.5	35.5	36.5
	Bypass Mode	(Extra high)	50Hz	26.0-28.0	29.5-30.0	34.0-35.0	32.5-34.0	34.0-36.0	37.0-38.5	39.5-40.5	38.0-39.0	41.0-42.5
			60Hz	27.5	31.5	35.5	33.5	35.5	38	41.5	39.5	42.5
		High	50Hz	24.0-25.5	25.0-27.0	30.0-32.0	29.5-31.0	33.0-34.0	35.5-37.0	38.5-40.0	36.5-37.5	39.5-41.0
			60Hz	24.5	25	29.5	29	34	35	39	36.5	40
		Low	50Hz	20.0-22.0	21.0-22.0	27.0-29.0	26.0-29.0	31.0-32.5	33.5-35.0	34.0-35.5	36.0-37.5	37.0-38.0
			60Hz	20	21	23.5	24.5	29.5	32.5	33.5	35.5	36.5
Temperature Exchange Efficiency (%)	(Extra high)	50Hz	81.5	78	74.5	76.5	75	76.5	73.5	76.5	73.5	
		60Hz	81.5	78	74.5	76.5	75	76.5	73.5	76.5	73.5	
	High	50Hz	81.5	78	74.5	76.5	75	76.5	73.5	76.5	73.5	
		60Hz	81.5	78	74.5	76.5	75	76.5	73.5	76.5	73.5	
	Low	50Hz	83	81.5	79.5	78	76.5	77.5	77	79	77.5	
		60Hz	83	81.5	79.5	78	76.5	77.5	77	79	77.5	
Enthalpy exchange Efficiency (%)	for heating	(Extra high)	50Hz	74.5	70	65	72	69.5	71	68.5	71	68.5
			60Hz	74.5	70	65	72	69.5	71	68.5	71	68.5
		High	50Hz	74.5	70	65	72	69.5	71	68.5	71	68.5
			60Hz	74.5	70	65	72	69.5	71	68.5	71	68.5
		Low	50Hz	76	74	71.5	73.5	71.5	71.5	71.5	73.5	72
			60Hz	76	74	71.5	73.5	71.5	71.5	71.5	73.5	72
	for cooling	(Extra high)	50Hz	69.5	65	60.5	64.5	61.5	64	60.5	64	60.5
			60Hz	69.5	65	60.5	64.5	61.5	64	60.5	64	60.5
		High	50Hz	69.5	65	60.5	64.5	61.5	64	60.5	64	60.5
			60Hz	69.5	65	60.5	64.5	61.5	64	60.5	64	60.5
		Low	50Hz	71	69	67	66.5	64	65.5	64.5	67	65.5
			60Hz	71	69	67	66.5	64	65.5	64.5	67	65.5
External dimensions (Length x Width x Height) (mm)			900 x 900 x 290			1140 x 1140 x 350			1189 x 1189 x 400		1189 x 1189 x 810	
Product weight (kg)			36	36	38	53	53	70	70	143	143	
Applicable duct nominal diameter (mm)			Ø100	Ø150		Ø200		Ø250		indoor side: Ø250, outdoor side: 283*730		

\* Sound Power Level is less than 70 dBA

# 10 Before calling for service

Check the points described below before asking for repair servicing.

Symptom	Cause
Operation does not start after pressing the button.	<ul style="list-style-type: none"> <li>Is the circuit breaker turned off?</li> <li>Has a power failure occurred?</li> <li>Does the  indicator light up? (The ventilation delay setting is set to "ON" and it is not malfunction. The Air to Air Heat Exchanger will start running after the time set has passed. Consult your dealer for details.)</li> </ul>
The unit runs though the operation lamp does not turn on.	Does the  or  indicator appear on the display? The nighttime heat purge operation or 24-hour ventilation is set to "ON". See page 9 for how to use the functions. Consult your dealer to change the setting to "OFF".
The unit starts running without any operation of the remote controller.	Has the unit just recovered from a power failure or have you just turned on the circuit breaker? (The settings concerning recovering from power failure are set to "ON". Consult your dealer for details.)

# 11 Troubleshooting

## CAUTION

If any of the following conditions occur, turn off the main power supply switch and immediately contact the dealer:


- Switch operation does not work properly.
- The main power fuse often blows out, or the circuit breaker is often activated.
- A foreign matter or water fall indoor the Air to Air Heat Exchanger.
- When the Air to Air Heat Exchanger does not operate even after the cause of the protective device activation has been removed. (The operation lamp and  on the remote controller are flashing. When  and a combination of E, F, H, L, or P and a number are displayed on the remote controller, also inform a qualified service person of the display content.)
- Any other unusual conditions are observed.

### Confirmation and check

When a trouble occurred in the Air to Air Heat Exchanger, the check code and the unit No. of the Air to Air Heat Exchanger appear on the display part of the remote controller.

The check code is only displayed during the operation. If the display disappears, operate the Air to Air Heat Exchanger according to the following "Confirmation of error history" for confirmation.

\* Unit No. of the Air to Air Heat Exchanger is 31-\*\*.





Check code      Unit No. of the Air to Air Heat Exchanger in which an error occurred

### Confirmation of error history

When a trouble occurred on the Air to Air Heat Exchanger, the trouble history can be confirmed with the following procedure. (The trouble history is stored in memory up to 4 troubles.)

The history can be confirmed from both operating status and stop status.



Procedure	Description
<b>1</b>	<p>When pushing  and  buttons at the same time for 4 seconds or more, the following display appears.</p> <p>If  Service check] is displayed, the mode enters in the trouble history mode.</p> <ul style="list-style-type: none"> <li>[01 : Order of trouble history] is displayed in CODE No. window.</li> <li>[Check code] is displayed.</li> <li>[Unit No. of the Air to Air Heat Exchanger in which an error occurred] is displayed in UNIT No..</li> </ul> <p>* Unit No. of the Air to Air Heat Exchanger is 31-***.</p> 
<b>2</b>	<p>Every pushing of  /  button used to set temperature, the trouble history stored in memory is displayed in order.</p> <p>The numbers in CODE No. indicate CODE No. [01] (latest) to [04] (oldest).</p> <p><b>CAUTION</b> Do not push  button because all the trouble history of the Air to Air Heat Exchanger will be deleted.</p>
<b>3</b>	After confirmation, push  button to return to the usual display.

- Check the troubles according to the above procedure.
- Ask an authorized dealer or qualified service (maintenance) professional to repair or maintain the Air to Air Heat Exchanger.
- More details of the error code are explained in Installation Manual.

**IMPORTANT INFORMATION AND WARNING:**

**READ BEFORE INSTALLING THE UNIT. KEEP IN A SAFE PLACE. THE INFORMATION IN THIS BOOKLET IS NEEDED FOR END OF LIFE, DISPOSAL OR REUSE OF THE UNIT.**

- We are very sensitive to environment and welcome the 2002/96/EC Directive WEEE (Waste Electrical and Electronic Equipment).
- This product is compliant with EU directive 2002/96/EC. It must be collected separately after its use is completed, and cannot be disposed of as unsorted municipal waste.
- The objectives of EU directive 2002/96/EC are to tackle the fast increasing waste stream of electrical and electronic equipment, increase recycling of electric & electronic equipment ("E"EE"), and to limit the total quantity of waste EEE ("WEEE") going to final disposal.
- The crossed-out wheeled bin symbol  that is affixed to the product means that this product falls under the Directive.
- The user is responsible for returning the product to the appropriate collection facility, as specified by your municipality or the distributor.  
In case of a new product installation, it may be possible to have the distributor pick up old WEEE directly.
- The producer, importer and distributor of the product are responsible for collection and treatment of waste, either directly or through a collective system.  
The list of our distributor in each country is shown below.
- In case of a violation of the Directive, sanctions are set in each country.
- We are in general following the "CECED interpretation," and consider the WEEE applicable to Portable units, Dehumidifiers, WRACs (Window Room Air Conditioners), Split Systems up to 12 kW, plug in refrigerators and freezers.
- Nevertheless, there may be differences among member state laws. In case country laws exclude some products from WEEE scope, country law must be followed, and WEEE obligations do not have to be followed for products that fall out of country law scope.
- This directive does not apply to products sold outside European Community. In case the product is sold outside the EU, WEEE obligations do not have to be followed, while compliance with local regulations must be ensured.
- For additional information, please contact the municipal facility, the shop / dealer / installer that sold the product, or the producer.

- ① Country  
② Name of Company responsible for WEEE.

①	②	①	②	①	②
Austria	AIRCOND, Klimaanlagen Handelsgesellschaft m.b.H Petersgasse 45, A-8010 Graz Austria	Ireland	GT Phelan Unit 30 Southern Cross Business Park Bray Co Wicklow, Ireland	UK	Toshiba Carrier UK Ltd Porsham Close, Belliver Ind. Est. Plymouth, Devon, PL6 7DB
Belgium	DOLPHIN NV, Fotografi elaan 12, B-2610, Antwerpen Belgium	Italy	Carrier SpA Via R. Sanzio, 9 20058 Villasanta (Milano), Italy	Czech Republic	AIRCOND, Klimaanlagen Handelsgesellschaft m.b.H Petersgasse 45, A-8010 Graz Austria
Cyprus	Carrier Hellas Airconditioning S.A.- 4g Andersen street-11525 Athens, Greece	Latvia	Carrier OY Linnavuorentie 28A 00950 Helsinki, Finland	Slovakia	AIRCOND, Klimaanlagen Handelsgesellschaft m.b.H Petersgasse 45, A-8010 Graz Austria
Denmark	GIDEX A/S, Korshøj 10, 3600 Frederikssund, Denmark	Lithuania	Carrier OY Linnavuorentie 28A 00950 Helsinki, Finland	Slovenia	AIRCOND, Klimaanlagen Handelsgesellschaft m.b.H, Petersgasse 45, A-8010 Graz Austria
Estonia	Carrier OY Linnavuorentie 28A 00950 Helsinki, Finland	Luxembourg	DOLPHIN NV Fotografi elaan 12, B-2610, Antwerpen Belgium	Spain	Carrier Espana S.L. - Paseo Castellana 36-38, 28046 Madrid
Finland	Carrier OY Linnavuorentie 28A 00950 Helsinki, Finland	Malta	CUTRICO Services Ltd, Cutrico Building Psala Street, Sta Venea HMR 16, Malta	Sweden	Carrier AB - P.O.BOX 8946-Arods Industrivag 32. S-402 73 Gothenburg
France	Carrier S.A. Route de Thi BP 49 01122 Montluel Cedex France	Norway	Carrier AB - P.O.BOX 8946-Arods Industrivag 32. S-402 73 Gothenburg, Sweden	Hungary	AIRCOND, Klimaanlagen Handelsgesellschaft m.b.H Petersgasse 45, A-8010 Graz Austria
Germany	Carrier GmbH & Co. KG Edisonstrasse 2 85716 Unterschleißheim	Poland	Carrier Polska Sp. Z.o.o. Postepu 14 02-676 Warsaw Poland		
Greece	Carrier Hellas Airconditioning S.A.- 4g Andersen street-11525 Athens, Greece	Portugal	Carrier Portugal - AR Condicionado LDA Avenida do Forte, Nr. 3 Editi cio Suecia I,Piso 1 Camaxide 2794-043 Portugal		
Holland	INTERCOOL Technics BV Nikkelstraat 39, Postbus 76 2980 AB Ridderkerk Netherlands				

## Declaration of Incorporation of Partly Completed Machinery

Manufacturer: Toshiba Carrier Corporation  
336 Tadehara, Fuji-shi, Shizuoka-ken 416-8521 JAPAN

Representative / TCF holder: Toshiba Carrier UK Ltd.  
Porsham Close, Belliver Industrial Estate,  
PLYMOUTH, Devon, PL6 7DB.  
United Kingdom

Hereby declares that the machinery described below:

Generic Denomination: Air to Air Heat Exchanger

Model / type: VN-M150HE  
VN-M250HE  
VN-M350HE  
VN-M500HE  
VN-M650HE  
VN-M800HE  
VN-M1000HE  
VN-M1500HE  
VN-M2000HE

Commercial name: TOSHIBA Air to Air Heat Exchanger

Complies with the provisions of the "Machinery" Directive (Directive 2006/42/EC) and the regulations transposing into national law.

Must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of Machinery Directive, where appropriate.

**NOTE**

This declaration becomes invalid if technical or operational modifications are introduced without the manufacturer's consent.

The manufacturer reserves the right to change any product specifications without notice.

<b>Information according to EMC Directive 2004/108/EC</b>	
(Name of the manufacturer)	<b>TOSHIBA CARRIER CORPORATION</b>
(Address, city, country)	336 Tadehara, Fuji-shi, Shizuoka-ken 416-8521 Japan
(Name of the Importer/Distributor in EU)	Toshiba Carrier UK Ltd.
(Address, city, country)	Porsham Close, Belliver Industrial Estate, PLYMOUTH, Devon, PL6 7DB. United Kingdom